

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6

55

28

REGISTRATION

NAME

60

ADDRESS

CREDIT CARD

62

NAME OF CHILD

EYES

FAVORITE COLOR

FAVORITE CARTOON

FAVORITE T.V. SHOW

60

63

DONE

The diagram shows a registration form on a screen. The screen is labeled 28. The form is titled 'REGISTRATION' and is enclosed in a box labeled 62. The form is divided into two sections by a dashed line. The top section contains three input fields: 'NAME', 'ADDRESS', and 'CREDIT CARD'. The bottom section contains five input fields: 'NAME OF CHILD', 'EYES', 'FAVORITE COLOR', 'FAVORITE CARTOON', and 'FAVORITE T.V. SHOW'. A 'DONE' button is located at the bottom right of the form. A label 55 points to the left side of the screen. A label 60 points to the 'NAME' field and the 'FAVORITE T.V. SHOW' field. A label 63 points to the 'DONE' button.

FIG. 7




FIG. 8

